

SaniPath Disinfecting Spray Liquid



PRODUCT DESCRIPTION

SaniPath Disinfecting Spray Liquid is a one-step germicidal cleaner and deodorant designed for general cleaning, disinfecting deodorizing and controlling mold and mildew on hard, non-porous inanimate surfaces. Quickly removes dirt, grime, mold, mildew, food residue, blood and other organic matter. Easily removes soap scum. Eliminates odors leaving areas smelling fresh and clean.

DIRECTIONS

See full label for complete directions.

Disinfection, Deodorizing and Cleaning: Remove visible soil prior to application of the product. Hold container six to eight inches from surface to be treated. Spray area until it is covered with the solution. Allow product to penetrate and the surface to remain wet for 3 minutes. No scrubbing is necessary. Wipe off with a clean cloth, mop, or sponge. The product will not leave grit or soap scum.

SPECIFICATIONS

Physical State: Liquid

Color: Blue

Odor: Fresh Clean Scent

pH: 11.5 - 12.5

Specific Gravity: 1.0

IDEAL FOR

Hospitals, Institutions, Office Buildings, Medical Buildings, Households and More.



Product: BE047

Mopec
(800) 362-8491
800 Tech Row
Madison Heights, MI 48071